

Daewoo **V23.05** Diagnostics List(Note:For reference only)

Vehicles	System	Sub System	functions					
			System Info.	Read Dtc	Clear Dtc	Data Stream	Actuation	System ID
LEMANS(RACER)	ENGINE SOHC	1.5 MPFI		√	√	√	√	
	ENGINE DOHC			√	√	√	√	
ESPERO	ENGINE SOHC	1.5 MPI(BEFORE 93MY)		√	√	√	√	
		1.5 MPI(AFTER 93MY)		√	√	√	√	
		1.8 MPI		√	√	√	√	
		2.0 MPI		√	√	√	√	
		2.0 TBI		√	√	√	√	
	ENGINE DOHC	1.5 MPI(BEFORE 93MY)		√	√	√	√	
		1.5 MPI(AFTER 93MY)		√	√	√	√	
		1.5 MPFI(BEFORE 93MY)		√	√	√	√	
		1.5 MPFI(AFTER 93MY)		√	√	√	√	
	ATUTOMATIC TRANSAXLE			√	√	√		
	ANTI-LOCK BRAKE SYSTEM			√	√	√		
SRS-AIRBAG			√	√				
PRINCE	ENGINE SOHC	1.8 MPFI		√	√	√	√	
		2.0 MPFI		√	√	√	√	
		LPG		√	√			
		2.0 (rus)						
	2.2L MPFI		√	√	√	√		
ANTI-LOCK BRAKE SYSTEM			√	√	√		√	
SUPER SALON	ENGINE SOHC	1.8 MPFI		√	√	√	√	
		2.0 MPFI		√	√	√	√	
	ANTI-LOCK BRAKE SYSTEM			√	√	√		√
		1.5L		√	√	√	√	

CIELO	ENGINE SOHC	1.8L		√	√	√		
		1.5L (rus)						
	ENGINE DOHC			√	√	√	√	
	AUTOMATIC TRANSAXLE			√	√	√		
	ANTI-LOCK BRAKE SYSTEM			√	√	√		
SRS-AIRBAG								
NEXIA	ENGINE SOHC	1.5L		√	√	√	√	
		1.8L		√	√	√		
		1.5(rus)		√	√	√	√	
	ENGINE DOHC	unlead 1.5 L		√	√	√	√	
		lead 1.5L		√	√	√	√	
	AUTOMATIC TRANSAXLE			√	√	√		
	ANTI-LOCK BRAKE SYSTEM			√	√	√		
SRS-AIRBAG			√	√				
NEW-PRINCE	ENGINE SOHC			√	√	√	√	
	ENGINE DOHC			√	√	√	√	
	ANTI-LOCK BRAKE SYSTEM			√	√	√		√
NEW-BROUGHAM	ENGINE SOHC			√	√	√	√	
	ENGINE DOHC			√	√	√	√	
	ANTI-LOCK BRAKE SYSTEM			√	√	√		√
LANOS	ENGINE SOHC	1.3L		√	√	√	√	
		1.5L		√	√	√	√	
	ENGINE DOHC	1.5L		√	√	√	√	
		1.6L		√	√	√	√	
	AUTOMATIC TRANSAXLE			√	√	√		
	ANTI-LOCK BRAKE SYSTEM	01.DELPHI		√	√	√	√	
		02.BOSCH		√	√	√	√	
SRS-AIRBAG			√	√				
ENGINE SOHC	1.5L		√	√	√	√		

NUBIRA	ENGINE DOHC	1.5L		√	√	√	√	
		1.8L		√	√	√	√	
		2.0L		√	√	√	√	
	AUTOMATIC TRANSAXLE			√	√	√		
	ANTI-LOCK BRAKE SYSTEM			√	√	√		
SRS-AIRBAG			√	√	√			
LEGANZA(TACUMA)	ENGINE SOHC	1.8L		√	√	√	√	
		LPG		√	√			
		2.0L		√	√	√	√	
	ENGINE DOHC	1.8L		√	√	√	√	
		2.0L		√	√	√	√	
		2.2L		√	√	√	√	
	LPG		√	√				
	AUTOMATIC TRANSAXLE	LPG		√	√	√		
	ANTI-LOCK BRAKE SYSTEM			√	√	√		√
SRS-AIRBAG			√	√	√			
MATIZ	ENGINE CONTORL	01.UNLEADED		√	√	√		
		02.LEAD		√	√	√		
	ANTI-LOCK BRAKE SYSTEM			√	√	√	√	
	SRS-AIRBAG			√	√			
NUBIRI II	ENGINE SOHC	2.0 L		√	√	√	√	
	ENGINE DOHC	1.5 L		√	√	√		
		1.6 L		√	√	√		
		2.0 L		√	√	√	√	
	AUTOMATIC TRANSAXLE			√	√	√		
	ANTI-LOCK BRAKE SYSTEM			√	√	√	√	
SRS-AIRBAG			√	√	√			
ENGINE CONTROL	GASOLINE(L4)			√	√	√	√	
	XK(SIEMENS L6)			√	√	√		

MAGNUS		LPG		√	√			
	AUTOMATIC TRANSAXLE	GASOLINE(~2002MY)		√	√	√	√	
		GASOLINE(2002MY~)		√	√	√	√	
		LPG		√	√	√	√	
	ANTI-LOCK BRAKE SYSTEM			√	√	√	√	
	SRS-AIRBAG			√	√			
	ISC			√	√	√	√	
REZZO	ENGINE CONTROL	UNLEADED		√	√	√	√	
		LPG		√	√			
	AUTOMATIC TRANSAXLE	GASOLINE		√	√	√	√	
		LPG		√	√	√	√	
	ANTI-LOCK BRAKE SYSTEM			√	√	√	√	
SRS-AIRBAG			√	√	√			
KALOS	ENGINE CONTROL			√	√	√	√	
	AUTOMATIC TRANSAXLE			√	√	√	√	
	ANTI-LOCK BRAKE SYSTEM			√	√	√	√	
	SRS-AIRBAG			√	√			
DAMAS/RABO	ENGINE CONTROL			√	√	√	√	
LACETTI/EXCELLE	ENGINE CONTROL	1.5L		√	√	√		
		1.6L		√	√	√	√	
	AUTOMATIC TRANSAXLE			√	√	√	√	
	ANTI-LOCK BRAKE SYSTEM			√	√	√	√	
	SRS-AIRBAG			√	√			
KALOS(06-)	ENGINE CONTROL	1.5 SOHC	√	√	√	√	√	
	AUTOMATIC TRANSAXLE		√	√	√	√	√	
	ANTI-LOCK BRAKE SYSTEM			√	√	√	√	
	SRS-AIRBAG			√	√			
	AUTOMATIC TRANSAXLE		√	√	√	√	√	

LACETTI(06-)	ANTI-LOCK BRAKE SYSTEM		√	√	√	√	√	
	SRS-AIRBAG			√	√			
MATIZ(M200)	ENGINE CONTROL	0.8 SOHC	√	√	√	√	√	
	AUTOMATIC TRANSAXLE			√	√	√	√	
	ANTI-LOCK BRAKE SYSTEM		√	√	√	√	√	
TOSCA	ENGINE CONTROL	2.0/2.5 L6 KOBD		√	√	√	√	
		LPI(EMS ECU)		√	√	√	√	
		LPI(IFB ECU)			√	√	√	√
	AUTOMATIC TRANSAXLE	Aisin 4단(1.8G/LPG2.0)	√	√	√	√	√	
	ANTI-LOCK BRAKE SYSTEM			√	√	√	√	
	SRS-AIRBAG		√	√	√	√		
GENTRA	ENGINE CONTROL	1.5 SOHC	√	√	√	√	√	
	AUTOMATIC TRANSAXLE		√	√	√	√	√	
	ANTI-LOCK BRAKE SYSTEM			√	√	√	√	
	SRS-AIRBAG		√	√	√	√		

(*) :Tested;

(?):Manual on website(www.x431.com)

Note:The final interpretation of the products belongs to LAUNCH TECH CO.,LTD.