

Mitsubishi V24.10 Diagnostics List (Note: For reference only)

Vehicle	System	Functions						
		Sys. Info.	Read code	Clear code	Data Stream	Actuation	Special Functions	Others
DIAMANTE	Engine		√	√	√	√		
	AT		√	√	√	√		
	A/C		√	√	√	√		
LANCER	Engine		√	√	√	√		
	ABS		√	√	√	√		
	A/C		√	√	√	√		
	SRS		√	√	√			
	AYC/ACD		√	√	√	√		
MIRAGE	Engine		√	√	√	√		
	ABS		√	√	√	√		
	SRS		√	√	√			
	AT		√	√	√	√		
CHALLENGER	Engine		√	√	√	√		
	ABS		√	√	√	√		
	SRS		√	√	√			
	AT		√	√	√	√		
	A/C		√	√	√	√		
MINICA	Engine		√	√	√	√		
	SRS		√	√	√			
EK WAGON	Engine		√	√	√	√		
	SRS		√	√	√			
TOPPO	Engine		√	√	√	√		
	SRS		√	√	√			
	AT		√	√	√	√		
	Engine		√	√	√	√		
	ABS		√	√	√	√		

LEGNUM	SRS		√	√	√			
	AT		√	√	√	√		
	A/C		√	√	√	√		
TOWNBOX	Engine		√	√	√	√		
	SRS		√	√	√			
	AT		√	√	√	√		
Aistsek	Engine		√	√	√	√		
	ABS		√	√	√	√		
	SRS		√	√	√			
	AT		√	√	√	√		
	A/C		√	√	√	√		
RVR	Engine		√	√	√	√		
	ABS		√	√	√	√		
	SRS		√	√	√			
	AT		√	√	√	√		
ENDEAVOR	Engine		√	√	√	√		
	ABS		√	√	√	√		
	A/C		√	√	√	√		
	SRS		√	√	√			
ECLIPSE	Engine		√	√	√	√		
	ABS		√	√	√	√		
	SRS		√	√	√			
	AT		√	√	√	√		
	A/C		√	√	√	√		
	CAMERA		√	√	√	√		
	Engine	√	√	√	√	√	1.Learned value reset(*)	1.Freeze Frame data(*)

OUTLANDER	ABS	√	√	√	√	√	1.Bleeding test mode (*) 2.Sensor calibration(*)	1.Freeze Frame data(*)
	SRS	√	√	√	√	√		
	AT	√	√	√	√		1.Clear CVT oil degradation level(*)	
	A/C	√	√	√	√	√		
	METER	√	√	√	√	√	1.Head lamp Auto leveling Diag mode(*) 2.Service reminder(*)	
	ETACS	√	√	√	√			
	Immo.	√	√	√	√	√		
	STEERING	√	√	√				
	4WD	√	√	√	√	√		
		Engine	√	√	√	√	√	1.Learned value reset(*)
I	ABS	√	√	√	√	√		
	SRS		√	√	√	√		
	AT		√	√	√	√		
	A/C		√	√	√	√		
	METER	√	√	√	√	√	1.Service reminder(*)	
	ETACS	√	√	√	√			
	4WS	√	√	√	√	√		
	Immo.	√	√	√	√	√		
	Engine		√	√	√	√		

GRANDIS	ABS		√	√	√	√		
	SRS		√	√	√			
	AT		√	√	√	√		
	A/C		√	√	√	√		
	METER		√	√	√	√		
	4WD		√	√	√	√		
COLT	Engine		√	√	√	√		
	ABS		√	√	√	√		
	SRS		√	√	√			
	AT		√	√	√	√		
	A/C		√	√	√	√		
	METER		√	√	√	√		
	ETACS		√	√		√		
	4WS		√	√	√	√		
DELICA	Engine	√	√	√	√	√	1.Learned value reset(*)	
	ABS	√	√	√	√	√		
	SRS	√	√	√	√	√		
	AT	√	√	√	√		1.Clear CVT oil degradation level(*)	
	A/C	√	√	√	√	√	1.Bleeding test mode(*) 2.Sensor calibration(*)	
METER	√	√	√	√	√	1.Head lamp Auto leveling Diag mode(*) 2.Service reminder(*)		

	ETACS	√	√	√	√			
	Immo.	√	√	√	√	√		
	STEERING	√	√	√				
	AFS	√	√	√	√	√		
TRITON	Engine	√	√	√	√	√	1.Fuel leakage check(*)	
	ETACS	√	√	√	√			
PAJERO	Engine	√	√	√	√	√	1.Learned value reset(*)	
	ABS	√	√	√	√	√	1.Bleeding test mode (*) 2.Sensor calibration(*)	
	SRS	√	√	√	√	√		
	AT	√	√	√	√	√	1.Clear CVT oil degradation level(*)	
	METER	√	√	√	√	√	1.Head lamp Auto leveling Diag mode(*) 2.Service reminder(*)	
	Immo.		√	√	√	√		
EK WAGON	Engine		√	√	√	√		
	AT		√	√	√	√		
	ABS		√	√	√	√		
	SRS		√	√	√			
	Engine	√	√	√	√	√	1.Learned value reset(*)	

LANCER EVO	ABS	√	√	√	√	√	1.Bleeding test mode(*) 2.Sensor calibration(*)	
	SRS	√	√	√	√	√		
	AT	√	√	√	√		1.Clear CVT oil degradation level(*)	
	A/C	√	√	√	√	√		

(*):Tested;

(?):Manual on website(www.x431.com);

Note:The final interpretation of the products belongs to LAUNCH TECH CO.,LTD.